


## Maxforce® Peacemaker Bait Injector™ Use and Maintenance Directions

The Maxforce Peacemaker is a precision bait injector that enables you to control the amount of gel applied per trigger pull by simply adjusting the spring-loaded control knob on the handgrip.

### Loading and operating:

1. Insert the gel reservoir into the rear chamber of the Peacemaker and gently screw the reservoir (clockwise) until firm. **Do not over tighten!**
2. Insert the reusable plunger into the back of the reservoir
3. Install a dispensing tip on the muzzle by turning the tip clockwise.
4. Prime the vacuum assembly by applying light pressure to the plunger while squeezing the trigger until gel begins to dispense (See Photo Below). Repeat this procedure if vacuum pressure is lost during use.



5. To adjust gel volume: squeeze trigger, depress control knob and slide to the desired setting. The amount of gel applied per trigger pull ranges from .04 grams (setting 1) to .25 grams (setting 5). "L" setting locks the trigger.

### Short-term storage:

1. Leave the bait gel reservoir attached to **prevent gel from drying out.**
2. Remove and clean dispensing tip.
3. Seal muzzle with an end cap.

### To clean or replace vacuum assembly:

- a. Remove the dispensing tip.
- b. Unscrew (counterclockwise) the muzzle and remove the vacuum assembly.
- c. Clean out old gel from the vacuum assembly with warm water and a thin rod (small paperclip will do).
- d. Apply petroleum jelly (or similar lubricant) to vacuum plunger (see figure?)
- e. Realign vacuum assembly correctly (see figure?) and screw muzzle back on (clockwise).

For assistance call;  
GNC Industries Inc.  
1401 Pace Road  
Pocahontas, AR 72455  
Phone: 800-462-2005 ext. 111 or 870-248-9901  
Email: [Sales@gnci.org](mailto:Sales@gnci.org)  
Website: [www.gnci.org](http://www.gnci.org)